

# CFV

USER MANUAL



## **TABLE OF CONTENTS**

Key features.....	2
About the CFV.....	3
Powering ON/OFF device.....	4
Inverted Display Function.....	5
Temperature controls.....	6
How to use the mouthpiece.....	7
How to load herb .....	8
Cleaning the device .....	9
Battery and charging .....	10
Safety disclaimers.....	11
Warranty and returns .....	15
Get in touch with us!.....	16

## KEY FEATURES

- Convection Heating Technology
- Stainless Steel Bowl
- Dual Internal 19350 Batteries
- Charge via USB-Micro 5PIN
- Compact OLED Display Screen
- Inverted Display Function

## OVERVIEW

2



REMOVABLE  
MOUTHPIECE

POWER BUTTON

SCREEN

INCREASE TEMPERATURE

DECREASE TEMPERATURE

CHARGING PORT



## **ABOUT THE CFV**

The full convection CFV now encompasses a stainless steel chamber for an amped up production of both taste and cloud . Pack as little or as much ground up herb into the chamber and place the rotatable mouthpiece when ready for use. Control the temperature one degree at a time to customize your sessions to your perfected settings. The OLED screen allows you to see the current temperature and battery life so you are able to be in control of your units longevity and range. Device can be paired up with the WPA in order to use with your glass water pipes for added filtration.

## POWERING ON/OFF DEVICE

The main button to power ON/OFF device is the large circular button located towards the top of the unit. Click 5 times in consecutive to power ON; the 0.86 inch OLED screen will illuminate with the Boundless Technology logo and will automate heat to the previously used settings. To power OFF device when your session is over press the power button another 5 times. The screen will shut off completely to indicate the unit is powered down.

POWER BUTTON



# Inverted Display Function

Display mode:  
0.86-inch OLED screen with optional  
inversion function.



“-”“+”

Power Button



“-”“+”

Power Button

**Inverted Interface Display Function:**  
When the device is off, press the Power Button, “+” and “-” keys (3 keys) at the same time for 2 seconds to invert the display screen by “180°”. Then press the main control key 5 times to turn on the device to enter the inverted interface display.

**Note:** If you want to go back to the non-inverted interface, then you need to invert the interface again by powering off the device and pressing the main control key, “+” and “-” keys (3 keys) at the same time for 2 seconds.

## TEMPERATURE CONTROLS

The temperature controls are two rectangular buttons located towards the bottom of the unit. The CFV has a full-range temperature Control (140°F-446°F or 60°C-230°C).

Simply click the increase or decrease button one time to raise or decrease the temperature at one degree.

Press and hold the increase or decrease button to automate raise or decrease temperature quickly.

If the temperature setting during heating period, after setting, the unit will heat automatically to the setting temperature.

If the temperature setting in Standby Mode, the unit will not begin to heat up until directed; hold down the power button for 3 seconds to heat chamber to the setting temperature.

INCREASE \_\_\_\_\_

DECREASE \_\_\_\_\_



To toggle between Fahrenheit and Celsius, simultaneously hold the two temperature buttons for 1 second.

\*Higher temperatures are generally recommended for bigger and denser clouds and low temperatures are suggested for a more pure taste and flavor.

## HOW TO USE THE MOUTHPIECE

The CFV has two different mouthpieces that may be used. The stock mouthpiece is a swivel mouthpiece that can be disassembled into smaller components for easier maintenance.

When finished loading the chamber place the rotatable mouthpiece back on top in order to use.

## **HOW TO LOAD HERB**

The updated CFV has a stainless steel chamber which can hold up to 0.5 grams of ground up herb. Use the loading ring (Sold Separately) to place on top of the chamber to make the loading process a lot cleaner and faster. When your session is over make sure to remove the used herb from the chamber right after use to prevent a build up of residue.

## **CLEANING THE DEVICE**

To ensure your CFV is running at maximum efficiency make sure to regularly clean your device. Use the cleaning brush to wipe the stainless steel bowl clean. The mouthpiece can be broken down for an easier clean. You may wipe the mouthpiece components including the stainless steel screen with 91% isopropyl alcohol to remove tougher residue. Make sure not to leave the isopropyl alcohol on for more than 10 minutes as it WILL cause cosmetic damage. DO NOT apply any isopropyl alcohol on the body of the device as again it will cause cosmetic damage that is not covered under the warranty.

## **BATTERY AND CHARGING**

When your CFV is running low on battery make sure to use the included USB cable to charge up the device. The CFV has two internal 19350 batteries that may not be removed. A complete charge may take anywhere from 2 ½ to 4 hours. Please be advised higher temperatures will drain the battery quicker with the average amount of sessions per charge equating to six.

It is not advised to leave unattended or to use the CFV while charging.

Also, to prevent from overheating do not leave the unit charging



overnight or on bare carpet/rug.

**NOTICE:** Lithium ion batteries are subject to degradation and reduced run time over the course of regular use. While Boundless Technology took great care in selecting premium quality long life lithium ion batteries due to their non-memory features and ability to cycle 300 times preceding degradation battery life will gradually diminish with extended use.

## **SAFETY DISCLAIMERS**

### **Warning**

Failure to follow these safety instructions could result in personal injury or damage. Users of

this device do so at their own risk. Neither Boundless Technology, LLC nor its retailers assume any responsibility or liability associated with the use/misuse of the device. Boundless Technology branded products are intended for adult use and consumption only.

### **Disclaimer**

This device is designed as a mobile solution for the practitioners of aromatherapy. This device is not intended for use with illegal substances.

### **Choking hazard**

The CFV contains small parts which may be a choking hazard to small children. Keep device away from children.

## **Handling the CFV**

- Do not drop, deform, bend, crush, puncture, incinerate, microwave, shred, paint, or insert foreign objects into a Boundless CFV or try to repair or modify the CFV yourself.
- Do not clean the CFV other than instructed by Boundless Technology, LLC.
- Do not use a damaged CFV charger or non Boundless Technology charger. Incompatible chargers may carry different voltage which may be a fire hazard.
- Use caution when handling the CFV as the heating chamber is hot when in use. Refrain from

direct contact with the main heating chamber when hot. Do not leave the device unattended when it is powered on or while the device is still hot.

- Do not leave in extreme temperatures.

### **Sleep protection**

The device is equipped with a safety sleep mode. When the device is powered on and after four minutes of use it will go into sleep mode to avoid overuse. Press and hold the power button for three seconds to resume use.

## **WARRANTY AND RETURNS**

**Boundless Technology, LLC warrants this device against defects in materials and workmanship under normal use for a period of 3 years with a separate 90-day warranty for the batteries from the date of retail purchase by the original end-user.**

**The limited warranty covers 3 years for electronics, structural integrity and attachments. 90-day warranty for the batteries. If a physical defect arises and a claim is made within the warranty period, at its option and to the extent permitted by law Boundless Technology will either repair the product defect or exchange the product with new device.**

## **GET IN TOUCH WITH US**

**E-Mail**

**info@bndlstech.com**

**Online Retail Site**

**BNDLSTECH.com**

**Follow Us @BNDLSTECH**









尺寸：75\*110MM

材质：128G铜版纸（封面过哑胶）

装订方式：骑马钉

大货料号：P800820007-00

P80082007-00	说明书	80082 英语说明书 A0 75*110MM 材质：128G铜版纸（封面过哑胶）20P 客户Logo“BD”
--------------	-----	---