Quick Start Guide	Product Breakdowr
<ul> <li>Use Caution when touching coil, always give time for the unit to completely cool before proceeding to touch, remove, or replace the coil.</li> <li>Do not charge on carpet or near any liquid.</li> <li>Do not use or leave in extreme temperatures.</li> <li>Keep away from and do not use around any person under the age of 21+</li> <li>This package contains small parts that may be dangerous to humans and</li> </ul>	- Mouthp
<ul> <li>pets if left unattended.</li> <li>Do not leave charging longer than 24 hours.</li> <li>Only place mouthpiece end into one's mouth.</li> </ul>	· LED Ind
About the Terp Pen XL  The Boundless Terp Pen XL is an electronic aromatherapy device specifically designed for consuming herbal concentrates.	
What's Included ⊕ Terp Pen XL, ⊕ Ceramic Coil, ⊕ Multi-Tool, ⊕ Cleaner Tool, ⊕ USB Cable	- Battery
Getting Started  1. How to attach, remove, and replace the coil  To install, screw the included coil clockwise into the body  To uninstall and replace, unscrew the coil counter-clockwise from the unit.	
<b>2. Charging</b> With the included Micro USB charging cable, connect the Terp Pen to a charging block. The red battery LED indicator will remain solid while charging and will turn off when fully	
<b>3. Cleaning the Coil</b> To clean the coil, remove outer shell from the unit. Inhale to activate coil and "burn-off" excess material.	
<b>4.</b> How to Maintain Terp Pen XL The Terp Pen XL can be broken down for easy cleaning (see product breakdown). Clean with isopropyl alcohol or alcohol prep pads. Do not get any liquid in USB port or on the coil connection located on the battery module.	- Outer S
5. Adjusting Voltage Tap three times near the USB port to cycle through the three voltage modes. 3.3v (Blue), 3.7v (Green), & 4.0v (Red)	
6. Battery Indicator Tap 2 times near the USB port to check battery level 100% - 66% (Green), 65%-33% (Blue), 32% - 0% (Red)	— Ceramio Coil
How it's Used 1. Remove magnetic cap to expose coil	- Cap
2. Inhale on the mouthpiece to activate coil	
3. While inhaling apply concentrate to heated coil and continue to inhale until the dose is consumed.	- Storage
Warranty	